



LOW VOLTAGE
OCC SENSOR(S)
(SEE APPLICABLE LIST)




WHITE
BLACK
RED

sPOD 3X 347



WHITE
BLACK
RED
WHITE/BLUE(STRIPE)
YELLOW
YELLOW/BLACK(STRIPE)

BLUE
BLUE/WHITE(STRIPE)
CAP




CLASS 2

WHITE
BLK/RED
BLUE
BLUE

CLASS 1

LOAD




BLK-120V
RED-347V

APPLICABLE SENSORS

CM 6 347	HMB 10 347
CM 9 347	HW 13 347
CM 10 347	RM 6 347
CM PDT 9 347	RM 9 347
CM PDT 10 347	RM 10 347
CMB 6 347	RM 50 347
CMB 9 347	RM PDT 9
CMB 10 347	RM PDT 10
CMB 50 347	WV 16 347
CMB PDT 9 347	WV PDT 16
CMB PDT 10 347	

sPOD 3X 347



BLACK
RED
YELLOW
YELLOW/BLACK(STRIPE)

BLUE
BLUE/WHITE(STRIPE)
WHITE
WHITE/BLUE(STRIPE)
CAP

sensorswitch
An Acuity Brands Company
www.sensorswitch.com
(800) 727-7483

This 3-WAY MANUAL ON SOLUTION w/
OCCUPANCY SENSOR: SINGLE GANG
SS-380

Book: NTS Date: 07/29/11 Revision: 1